



IRUA TECH Ind.

Order Technical sheets / Automatic Control Valves




www.irua.es

PRESSURE CONTROL SPRING:
Adjust the rod nuts in order to
increase or decrease the discharge
pressure.
The valves are delivered adjusted
as per customer's indications.

DISCHARGE PRESSURE ADJUSTMENT

OUTLET FLANGE:
Free or driven.



INLET FLANGE

Fig. 4660
Automatic Direct Action Pressure
Relief Valve